

BATERIJA ZA LAPTOP ACER TM5500 11.1V-5200MAH

Naziv: BATERIJA ZA LAPTOP ACER TM5500 11.1V-5200MAH

Slika:



Šifra: #BM46813751726227658356

Barkod: 8600412068135

Proizvođač: 3G

Detalji

Kategorija: BATERIJE ZA LAPTOP

Oznake:

Atributi:

CenaCena sa PDV: 2,600.00 RSD *WEB CENA
2,860.00 RSD *Cena za odloženo web plaćanje**Ostalo**Opis: **Odgovara sledećim modelima laptopova:**
Aspire 3040, Aspire 3050, Aspire 3053, Aspire 3053WXM, Aspire 3054WXCi, Aspire 3200, Aspire 3600, Aspire 3602, Aspire 3603, Aspire 3608, Aspire 3680, Aspire 3681WXM, Aspire 3682NWXC, Aspire 3682WXC, Aspire 3682WXM, Aspire 3683WXM, Aspire 3684NWXM, Aspire 3684WXCi, Aspire 3684WXM, Aspire 3686NWXM, Aspire 5030, Aspire 5050, Aspire 5051ANWXM, Aspire 5051AWXC, Aspire 5051AWXM, Aspire 5052ANWXM, Aspire 5052NWXM, Aspire 5053NWXM, Aspire 5053WXM, Aspire 5500, Aspire 5500Z, Aspire 5501, Aspire 5502, Aspire 5503, Aspire 5504, Aspire 5504WXM, Aspire 5507, Aspire 5570, Aspire 5570AWXC, Aspire 5570AWXM, Aspire 5570Z, Aspire 5571, Aspire 5571AWXM, Aspire 5572AWXM, Aspire 5573AWXCi, Aspire 5573ZWXM, Aspire 5575ZNWXM, Aspire 5580, Aspire 5583NWXM, Aspire 5583WXM, Aspire 5584WXM, Aspire 5585WXM, Aspire 9510, Extensa 2400, Extensa 2480, Extensa 4014NWXM, Extensa 4014WXM, TravelMate 2400, TravelMate 2403, TravelMate 2403 WXCi, TravelMate 2403 WXM, TravelMate 2404, TravelMate 2480, TravelMate 2480-2196, TravelMate 2480-2698, TravelMate 2480-2968, TravelMate 2482WXM, TravelMate 2483WXM, TravelMate 2484WXM, TravelMate 3210, TravelMate 3210Z, TravelMate 3211, TravelMate 3211 WXM, TravelMate 3212, TravelMate 3213, TravelMate 3220, TravelMate 3222, TravelMate 3222 WXM, TravelMate 3224, TravelMate 3224 WXM, TravelMate 3224WXM, TravelMate 3230, TravelMate

3242NWXMi, TravelMate 3260, TravelMate 3260ANWXCi, TravelMate 3260WXM, TravelMate 3261AWXM, TravelMate 3261NWXCi, TravelMate 3262, TravelMate 3262WXM, TravelMate 3270, TravelMate 3270-6569, TravelMate 3273NWXMi, TravelMate 3273WXM, TravelMate 3274, TravelMate 3274WXM, TravelMate 4310, Aspire 3030, Aspire 3040, Aspire 3050, Aspire 3053, Aspire 3053WXM, Aspire 3054WXCi, Aspire 3200, Aspire 3600, Aspire 3602, Aspire 3603, Aspire 3608, Aspire 3680, Aspire 3681WXM, Aspire 3682NWXC, Aspire 3682WXC, Aspire 3682WXM, Aspire 3683WXM, Aspire 3684NWXMi, Aspire 3684WXCi, Aspire 3684WXM, Aspire 3686NWXM, Aspire 5030, Aspire 5050, Aspire 5051ANWXM, Aspire 5051AWXC, Aspire 5051AWXM, Aspire 5052ANWXM, Aspire 5052NWXMi, Aspire 5053NWXMi, Aspire 5053WXM, Aspire 5500, Aspire 5500Z, Aspire 5501, Aspire 5502, Aspire 5503, Aspire 5504, Aspire 5504WXM, Aspire 5507, Aspire 5570, Aspire 5570AWXC, Aspire 5570AWXM, Aspire 5570Z, Aspire 5571, Aspire 5571AWXM, Aspire 5572AWXM, Aspire 5573AWXCi, Aspire 5573ZWXM, Aspire 5575ZNWXM, Aspire 5580, Aspire 5583NWXMi, Aspire 5583WXM, Aspire 5584WXM, Aspire 5585WXM, Aspire 9510, Extensa 2400, Extensa 2480, Extensa 4014NWXMi, Extensa 4014WXM, TravelMate 2400, TravelMate 2403, TravelMate 2403 WXCi, TravelMate 2403 WXM, TravelMate 2404, TravelMate 2480, TravelMate 2480-2196, TravelMate 2480-2698, TravelMate 2480-2968, TravelMate 2482WXM, TravelMate 2483WXM, TravelMate 2484WXM, TravelMate 3210, TravelMate 3210Z, TravelMate 3211, TravelMate 3211 WXM, TravelMate 3212, TravelMate 3213, TravelMate 3220, TravelMate 3222, TravelMate 3222 WXM, TravelMate 3224, TravelMate 3224 WXM, TravelMate 3224WXM, TravelMate 3230, TravelMate 3242NWXMi, TravelMate 3260, TravelMate 3260ANWXCi, TravelMate 3260WXM, TravelMate 3261AWXM, TravelMate 3261NWXCi, TravelMate 3262, TravelMate 3262WXM, TravelMate 3270, TravelMate 3270-6569, TravelMate 3273NWXMi, TravelMate 3273WXM, TravelMate 3274, TravelMate 3274WXM, TravelMate 4310

Kompatibilni kodovi:

3UR18650Y-2-QC261 BATEFL50L6C40 BATEFL50L6C48
BT.00603.006 BT.00603.010 BT.00603.025 BT.00603.030
BT.00604.001 BT.00604.004 BT.00604.012 BT.00903.007
LC.BTP00.001 LC.BTP00.002 LC.BTP01.006 LIP6220QUPCSY6
BATEFL50L9C72 3UR18650F-3-QC262 LIP6220QUPC